

## **BACTERIA** (*E. coli* & total coliform)

- 1. Label Your Sample Cup with tablet** in permanent marker with:
  - ✓ Your Name
  - ✓ Your Phone Number
  - ✓ Sample ID or location
- 2. Flush the line for 5 minutes.**

This ensures the pipes in a house have been cleared of sitting water.
- 3. Clean the fixtures/faucets.**

Use bleach or rubbing alcohol and clean paper towels, you can flame full metal fixtures.
- 4. Remove the Residue.**

Run the water for approximately 30 seconds to remove residue.
- 5. Collect Your Sample** (cup with tablet).

Fill the Sample Cup as close to the faint line labeled “EPA fill line” as possible. Leave tablet in cup.
- 6. Complete the Order Form.**

Be sure to record dates and times. Potable/Drinking Water choose Pres/Abs. Surface or Ag Water choose MPN.
- 7. Prepare Your Sample** for Transit.

Use zipper bag to protect from ice during transportation.
- 8. Drop off Your Sample.**

Water samples need to be received within 24 hours of collection. Office hours M-F 8:00am -4:30 pm

**Only Bacteria can be analyzed from this sample vial.**

## **HARDNESS | NITRATES | NITRITES**

- 1. Label Your Sample Cup(s)** in permanent marker with:
  - ✓ Your Name
  - ✓ Your Phone Number
  - ✓ Sample ID or location
- 2. Rinse Cup** with the sample water before collecting
- 3. Collect sample.**

Fill with sample water to the top. Seal cap securely.
- 4. Complete the Order Form.**

Record dates and times. You can select hardness, nitrates, and/or nitrites. Be aware fees apply for each analyte you choose.
- 5. Prepare Your Sample** for Transit.

Use zipper bag to protect from ice during transportation.
- 6. Drop off Your Sample.**

Water samples need to be received within 36 hours of collection.

**You need one snap top sample vial for all three of these analytes.**

**Only hardness, nitrates, and nitrites can be analyzed from this sample vial.**

## **IRON | COPPER | LEAD**

- 1. Label Your Sample Cup(s)** in permanent marker with:
  - ✓ Your Name
  - ✓ Your Phone Number
  - ✓ Sample ID or location
- 2. Rinse Cup** with the sample water before collecting
- 3. Collect sample.**

Fill with sample water to the top. Seal cap securely.
- 4. Complete the Order Form.**

Record dates and times. Select iron. Be aware fees apply for each analyte you choose.
- 5. Prepare Your Sample** for Transit.

Use zipper bag to protect from ice during transportation.
- 6. Drop off Your Sample.**

Water samples need to be received within 36 hours of collection.

**You need one screw top bottle for this analyte.**

**Bottles from our facility have a colored dot on the bottom.**

**These bottles have been cleaned especially for certain metals.**

# CLEAN WATER LAB

---

address | 6343 S NC 9 HWY

Columbus, NC 28722

e-mail | [reports@cleanwaterlabtech.com](mailto:reports@cleanwaterlabtech.com)

website | [www.cwlabtech.com](http://www.cwlabtech.com)

phone | (828) 393-4136

---

Our Hours: 8:00 am- 4:30 pm , Monday-Friday



## YOU PICK + IRON/COPPER/LEAD WATER TESTING KIT

**How it works:** Bring us back these sample vials filled with your water and we'll test up to 8 different contaminants!\*

\*Additional fees may apply!

1/12/2021

We Want to Be the Best! Please fill out and return this survey to help us improve.

1. The instructions were easy to understand. Circle one.



yes



neutral



no

2. I would recommend Clean Water Lab to a friend. Circle one.



yes



neutral



no

Comments: